

TRIUMPH BASE/ROVER START-UP IN FIELD

These instructions assume that base, radio, and LS are properly configured and are powered up. If this does not work, see troubleshooting on page 2.

other procedures.

4. This will take you
 1. 1. Go to [HOME PAGE].
 2. Tap on [STEP UP]. This will take you to the [SET UP] screen
 3. Look at the top left block (name). Unless you are doing something unusual this will read [ROVER SPC) or (whatever name that you want to use). Your goal is for it to read this and work.
 4. Tap [BASE ROVER SET UP] near the lower left. This brings up a screen to check connections and information about the BASE on the L/H side and information about the ROVER on the R/H side. It has the name of the set-up as the first line of the BASE info.
 5. Tap {CONNECT} to connect the Base and Rover. Expect to change to {CONNECT TO BLUE TOOTH DEVICE} Screen.
 6. Tap on {BASE} and choose Base.
 7. Tap on {CONNECT}. This may connect the Rover to the Base or you may have to wait a short time and then tap {CONNECT at the bottom of the screen} and then tap {OKAY}.
 8. Wait while action is completed. Blue Tooth may not work behind a truck.
 9. If the Base is on the last point that it was on the previous session you are thru. Otherwise continue.
10. Tap {STOP BASE}.

11. Tap on {DISPLAYED DATA FOR COORDINATES} on the right side. This brings up a screen with choices about Base Location.
12. Choose one of the items. {FROM LIST} or {ENTER} or {AUTO} and tap on it. Look at the next 2 boxes and tap {OKAY}.
13. Screen from item 11 should come back.
14. Tap {SEND TO BASE}. You will be ask to confirm.
15. Make changes or tap {YES, SEND TO BASE}.
16. This will you back to the BASE / ROVER information screen in step 2.
17. Review and tap [NEXT] at the lower left side of the screen. This will take you to the [COLLECT SCREEN].

TROUBLESHOOTING THE ABOVE INSTRUCTIONS

Problem: The base and rover are connected and both are receiving, but the box on the [COLLECT] screen that should show [FIXED] or [FLOAT] or [STAND ALONE] is dark.

Action: Look at step # 2. Is the set-up name on the top line of the left side ROVER SPC, (or whatever name you use)? If not, go back to the [HOME SCREEN] and tap [SET UP]. This will take you to the next screen. Look at the name at the top left of the screen. It must be ROVER SPC (or whatever name you use). If it not the correct name, tap on [RECALL]. This will take you to the [RECALL SETUP] page. Select the correct name and tap [RECALL]. Tap [ESC]. This take you back one screen. Check the name and tap [ESC].

Page 3 of 3 may be trash

Problem: It still don't work.

Action: Check instructions for BASE / ROVER SETUP.

3. Tap on the {DATA} under the name of the Base. Note: if there is no data, the book out.