



QUICK START GUIDE TO THE TRIUMPH-LS

Table of Contents

Introduction	3
Anatomy - Exterior of TRIUMPH-LS	4
Screen Anatomy - Home Screens	7
Charging the Batteries.....	9
Help & Support.....	9
Turning on the TRIUMPH-LS	9
Calibration.....	10
Updates.....	10
Points and Point Filters.....	11
Adjusting a Base Station Position.....	15
Manually Entering New Base Station Coordinates.....	15
CoGo Tool DPOS	16
Real-Time Position Shift	17
Coordinate Systems	18
Adding a State Plane Coordinate System.....	18
Creating an Adjusted Grid-To-Ground C.S.	19
Files and Data Exchange.....	23
Data Base Structure and Customize Screen	23
Working with WMDC.....	23
Mounting a Cloud Drive	24
Mounting a Shared Network Folder	26
Importing Points From a Text File.....	27
Exporting Points To a Text File	28
Exporting Photos, Screenshots, GNSS Data.....	30
Exporting Project Archives	30
Exporting a Project Report	30
ShapeTags & Codes.....	31
Setup.....	32
Base/Rover Setup	34
Collect.....	44
Action Profile Setup	46
RTK Verification and Validation	48
Recommended Collection Settings.....	49
Collect Screen Anatomy.....	52
Stake.....	54

This **Quick Start Guide to the TRIUMPH-LS** contains the basic information a user new to J-Field, the field software of TRIUMPH-LS and VICTOR-LS, needs to know to get started working quickly. More information and details are provided in the **User's Guide to the TRIUMPH-LS**. J-Field also contains its own ever-growing on-board manual with context sensitive help files for various screens. Press the



hardware **(Help)** button to learn more about each screen.



J-Field is rapidly being developed with new updates typically being released monthly; because of this, screenshots and features in this guide may appear differently from the latest version of J-Field. Be sure to check www.javad.com/jgnss/ and the user forum at <http://support.javad.com> frequently to stay current on all of the breaking news and innovative developments from JAVAD GNSS. Details about new features can also be found in the **Application Notes** accessed from the **Support** menu.

Central to J-Field are four key concepts, briefly introduced here and that are discussed more fully in their respective sections:

Project - A user-defined job identifier with its own database file and folders for storing data


Page - Each **Project** has 10 pages that can contain points and lines and can be toggled on or off similar to CAD layers. Each **Page** has the option of having its own coordinate system.

ShapeTags - User-defined tags for points that can be assigned to create lines between points with like **ShapeTags**

Codes - Each point has a **Code** field to store commonly used point descriptions. Once a **Code** has been created, it can be recalled from the **Codes Library** or from the **Favorite Codes** list.


Anatomy - Exterior of TRIUMPH-LS


Top, Left and Front Faces




Anatomy - Exterior of TRIUMPH-LS

Bottom, Right and Back Faces






Screen Anatomy - Home Screen 1



Screen Anatomy - Home Screen 2



Charging the Batteries

The TRIUMPH-LS AND VICTOR-LS come from the factory with the batteries charged and ready to use so you can begin exploring its interface and familiarizing yourself right away while reading this manual.



Lithium Ion batteries should not and cannot be charged when their temperature is above 40° C (104° F). They charge faster when they are cool. Therefore, it's best that you turn off the unit when charging. Charging the unit when it's on will cause it to charge more slowly (up to 40° C) due to its increased temperature.

Some of the cables and their connectors used in charging the equipment may not be familiar to you. ODU style connectors are superior for a broad range of industrial power, communications and data applications that demand a precision-engineered, secure and robust solution.

When charging your receiver, be sure to line up the red dots on the connector and the charging port on the LS. Note



that the four LEDs have different meanings when the LS is on from their meanings when the unit is being charged. When the unit is on, you'll want to pay attention to the upper left LED as it alerts you of an immediate issue.

Anytime the TRIUMPH-LS displays this LED as red, press the warnings key to learn more and take any necessary corrective measures.

Help & Support

J-Field contains its own ever-growing on-board manual with context sensitive help files for various screens. Press the hardware **Help** button to learn more about each screen. Contact information of the Live Technical Support team members are listed in Support>Live Technical Support. You are also encouraged to submit your feedback and questions to the user's forum located at <http://support.javad.com>.


Turning on The TRIUMPH-LS

Powering the TRIUMPH-LS on is pretty straightforward with the underlying operating system; Windows Embedded Compact 7.0, loading first and then J-Field subsequently booting up.



There are occasions when the system might freeze. Should you experience this, simply depress the power key and hold down until the unit powers off, about 10 seconds. Any data collected up to that point will be saved.

Any data collected up to that point will be saved.



Calibration

The TRIUMPH-LS is an advanced scientific surveying instrument. It is highly sensitive to its environment and includes a built-in magnetometer and 3-axis accelerometer.

For the visual stakeout features and the *Ahead/Back* and *Right/Left White Boxes* in the *Stake Action* screen to work correctly, the electronic compass readings need to be accurate. It is recommended to check the compass calibration before beginning work at a new location. To check the calibration, rotate the TRIUMPH-LS 360° and observe the compass readings in the *Collect* or *Stake Action* screen. There should be no twitching, quick jumps, or reversals of the displayed bearing or azimuth, just as a real compass would perform. If this is not the case, the compass needs to be recalibrated or it may not be in a suitable environment for its use. Follow the instructions on the screen to calibrate the compass. When calibrating the compass, choose an area removed from overhead power lines, parked automobiles and other ferrous materials which cause magnetic disturbance. The electronic compass works in areas that are electromagnetically uniform.

The *Level* calibration typically only needs to be preformed once. Follow the instructions on the screen to calibrate the level.

The level sensors are sensitive to the internal temperatures of the TRIUMPH-LS. To fine tune the level calibration, a *Level Offset* calibration needs to be done. It is located in the *Action Setup* menu. It is necessary to reperform this calibration as the internal temperature of the TRIUMPH-LS changes. If the *Correct For Tilts* option is enabled and the

most accurate positions are desired, it is essential to monitor the *Level Offset* calibration and recalibrate when necessary.

The *Camera* needs to be calibrated if you intend to use the camera's *Visual Angle* or *Camera Offset Survey* tools. This only needs to be done once.




Updates

Keeping your TRIUMPH-LS up to date is nearly effortless; however, you do need to ensure that you have Internet access in order to download the firmware and software updates.


The TRIUMPH-LS will automatically detect nearby WiFi networks. To see the detected networks, as well as their respective signal strength, tap on the *WiFi* icon in the top row of icons on the Home screen and then at the bottom of that screen tap on *Network*. Select the desired access point, tap on *Connect*, enter the case sensitive password, if any, and the connection should be established. Once connected to a WiFi network it will be remembered and added to the Favorites and the connection to it will become automatic when it is detected.

If you do not have WiFi or for some reason are unable to connect to it, but do have a wired local area network, you can connect the TRIUMPH-LS to your network using a cable connected to the LAN port and your network interface card or router. A wireless network can also be used if you have an installed SIM card data plan with sufficient data.



Points

Tap on this icon to review points, alignments, trajectories in J-Field.




Points Screen Displaying Design Points

Each point can have up to five types of coordinates that are displayed in the *Points* screen:

- **Design Coordinates** - Imported and manually entered coordinates are populated into this field and stored in the *Project's* database file with their native coordinate system as was selected when they were imported.
- **Survey Coordinates** - These are coordinates determined from GNSS observation. All surveyed points are stored with *Survey Coordinates* with WGS84 (ITRF 2008) coordinates.
- **Base Station Coordinates** - When a point is surveyed with RTK corrections, the base station coordinate is saved.
- **Survey Shifted Coordinates** - When a point's base

station coordinates have been adjusted or shifted, the shifted survey coordinates are displayed along with the unadjusted survey coordinates (*Survey Origin*).

- **Base Station Shifted Coordinates** - When a point's base station coordinates have been adjusted or shifted, the shifted base station coordinates are displayed along with the unadjusted base station coordinates (*Base Station Origin*).




Edit Point Screen Displaying a Point with Each Type of Coordinate

Point Filters


Points are displayed in the coordinate system of the *Current Page* in the CoGo functions and in the map. All new *Survey Points* and points created with the CoGo functions are created in the *Current Page*. The *Current Page* can be selected by tapping  (*Filter Button*) to open the *Filter* screen. The First row displays buttons for each of the 10 pages. The *Current Page* is highlighted green while visible pages are shown with bold numbers and hidden pages are shown with small gray numbers. Tap a page button to

toggle it between visible and hidden. Objects in hidden pages are not display in the list of objects or on the map.



Filter Screen - Current Page is 1, Page 0 is hidden

The **Pages** screen can be open by tapping **Pages**. It displays the page names and allows it to be edited along with the coordinate system and color.




Pages Screen - Current Page is 1, Page 0 is hidden

The **Current Page** is set with the toggle on the left while the

visibility of **Pages** are controlled with the check box options on the right.

The **In All Projects** toggle will display points from all projects. This is usually not recommended as it will slow J-Field down if many points exist.

Points can be sorted in the displayed points list by **Distance**, **Alphabetical** or **Chronological**. Notice the down arrow in the corner of the **Distance Filter** button. Holding this button down will initiate a **Long Click** and present additional options for the **Distance Filter**.




Origin of Distance Filter Options

Hide Staked hides points that have already been staked. A point is considered staked after it has been staked with a surveyed coordinate accepted for it.

Hide Vertices hides points created from imported lines from being displayed in the point's list. J-Field defines lines as connections between points so every line must have points at its vertices. For this setting to be applied the **Hide Line Vertices** option must be checked in the **Common Settings** screen when AutoCAD, DGN or Shapefiles are imported.

The  (**Add**) button allows new points to be added; with the **Survey** button selected you will be taken to the Stake Action screen; with the **Design** button select you can add a point with one of the four options shown.




Add Point Screen for Design Points

The  (**Edit**) button opens the Edit Points screen (shown on the previous page) to allow the various parameters of the point to be modified.

The  (**Delete**) button deletes the selected object. A **Long Click** (tap and hold) on this button deletes all objects currently shown in the list, i.e. taking into account the general filter and name filter.

The  (**Type Filter**) opens the **Type Filters** screen. It allows points to be filter by **Solution Type** and **Processing Type** (post-processing options are in development and coming soon).



Type Filters Screen

The  button enables/disables the name filter. When it is on, four additional fields are shown to the right: one text field and three switches captioned ,  and . Enter the search text in the text field and specify which switches are active (activated switches have a light blue background while deactivated switches are white):

 looks for names which begin from the search string;

 looks for names which contain the search string in the middle, but do not begin or end with it;

 looks for names which end with the search string.

Activating more than one switch combines the results:

activate  and  searches for names which either begin with the search string or contain it in the middle.

To search for a range of numbers use the format of *number1..number2*. This format matches names which contain numbers in range between *number1* and *number2* (in the position defined by switches). E.g. if you enter 3..9 (assuming all switches are on), it will match names 3, *Stake04a*, *Pt9*, but not names *14* or *Point19a*.

The  (*Additional Actions*) icon contains a list various options, settings and functions related to the *Points* screen. More information about the items contained in this menu can be found in each of the actions' Help screen. Of particular interest are *Settings* and *Cluster Average*.

Settings has options to allow the *Point Name*, *Code* and *Description* to all be displayed in the left panel of the *Point* screen rather than just displaying the *Point Name*.

Cluster Average finds groups of points in a cluster and creates an averaged point from the group.



Additional Actions screen

The information panel (the right blue panel) may contain more text than fits in its view. If this is the case, tap and drag the panel to scroll its contents.


Adjusting a Base Station Position

When a GNSS RTK base station is started by assuming an autonomous position, it is necessary and good practice to later adjust and correct the coordinates with a GNSS solution referenced from known coordinates. J-Field, has the ability to adjust the RTK base station coordinates and RTK points surveyed using corrections from that base station. There are three methods that can be used to accomplish this.


Manually Entering New Base Station Coordinates

Base station coordinates can be updated manually by entering new coordinates for the base station. These new coordinates can be obtained through post-processing the base station data with OPUS or Javad's DPOS web interface. Follow these steps to apply the corrected coordinate to the base station and adjust all the points from this base station through J-Field:

1. Select an RTK or base station point in the *Points* screen.
2. Tap on the blue information panel displayed on the right side of this screen to view the *Base Rover Statistics* screen.
3. Tap the *Base* button and you will be prompted to enter the corrected coordinates for the base station.
4. Enter the new coordinates and tap *OK*.



Base Rover Statistics Screen



Prompt to Update the Coordinate of the Base Station

J-Field will then search for all the points contained in the current project with the same original matching base station coordinates and apply offsets to adjust all these coordinates into the known coordinate system. The adjusted coordinates along with the original base station and surveyed origin coordinates will still remain stored in the database for documentation purposes and so that adjustments can be undone or modified if necessary.

CoGo Tool DPOS

When a Javad base station is started with J-Field using Base/Rover Setup, the raw GNSS data is automatically saved in the base station receiver. When the base station is then stopped with Base/Rover Setup, the data is downloaded into J-Field so that it will be available for post processing DPOS.

To post-process the data, open the DPOS tool found in the CoGo menu and select the base file you wish to process. With the TRIUMPH-LS connected to the Internet, tap the

DPOS

button to upload the file to DPOS. You will usually need to wait until the next day before submitting files to OPUS or DPOS as CORS (Continuously Operating Reference Stations) data isn't available immediately. After the DPOS solution has been received, that's files status will become "Waiting for adjusting permission". Review the solution by tapping the blue information panel to open the Base/Rover Statistics for the base station point. An acceptable solution should have a Fixed solution, a 3dRMS of less than 3 cm (0.10') and make use of multiple stations; if this is not the case, the data can be reprocessed again at a later time by pressing the DPOS button again.


If satisfied with the solution, click

Adjust

to adjust the base station coordinate and all the survey points collected during the base station session. After adjustment, the option to undo the adjustment will always exist. Tap

Undo

if you ever desire to undo the adjustment. The data can then be processed again with the DPOS button if desired.



CoGo DPOS - The Filter is Applied to Show Current Project Base Files Only

Base	GEO: 39°56'46.82228"N 083°00'22.67552"W	612.2249	@2010.00
	GRID: 709313.5946 1826544.1652 723.3067		
Old	GEO: 39°56'46.88473"N 083°00'22.70465"W	601.6008	@2010.00
	GRID: 709319.9271 1826541.9319 712.6825		
SHIFT: 160°34' 6.71 10.62			
FIX: Yes	OBS: 4060/4060	2016-01-08 21:57:13 (00:30:30)	
HRMS: 0.005	VRMS: 0.006	3dRMS: 0.008	95% Confidence Ellipse
Geometry: 1.015	CORS: COLB,MTVR,OHHO,OHLI		
σh: 0.011			
σ: 89°20'35"	σ _s : 0.011	σ _b : 0.005	
ANT: HGT:2.025m JAVTRIUMPH_2A NONE			
Point: Park100 DefCode			
Project: LewisRd	Page: Page1	Units: ft	

Base Rover Statistics Screen - An acceptable DPOS solution, Fixed, 3dRMS < 3cm and multiple stations (CORS)

The icons next to file displayed in the DPOS screen indicate the status of the file:

- Downloading (from base receiver to J-Field)
- Uploading
- Awaiting DPOS results

- Waiting for adjusting permission
- DPOS result applied


Real-Time Position Shift

Real-Time Position Shift, allows real-time corrections to be applied to receive base station corrections. A base station can be started with an autonomous position and then corrected by surveying a point with known coordinates. The known point could be a point previously surveyed with a base station setup in a different location. This feature is useful for several scenarios:

- ◆ You need to move or "leapfrog" your base station to extend the radio range into a new area.
- ◆ Your original base station point has been lost.
- ◆ You wish to save time by starting the base station with it mounted to the top of your vehicle. Setting the base station and radio up on the top of vehicle by mounting it to a roof rack or using a magnet mount saves time by eliminating the need to setup tripods and can help protect the base station from disturbances or theft in undesirable locations. For the best performance, the base station should be mounted in a near level position so that phase center variations and antenna offsets are correctly applied. If you are parked on a sloped surface, a swivel mount can be used to level the receiver on the top of your vehicle. Your vehicle should be parked on solid ground where it will not move or sink.


The *Real-time Position Shift* function can be accessed from the *Setup>General Group Edit>Advanced Real-time Position Shift*. In this screen, select a point you have collected RTK coordinates from with an autonomous base station and then the known coordinates of this point. Check the *Apply Shift* and the shift will be applied to all the RTK surveyed points found in the current project collected from this base station. This shift will continue to be applied

to all the points surveyed from this base station.




Position Shift Screen

Real-time Position Shift can also be accessed from the Collect Action screen by clicking the button below the Start button and changing the collection mode to Shift. In this mode select the *Known Point* and then press *Start* from the action screen to collect a point so that the offset can be calculated. After it has been calculated you can apply the shift.




Position Shift Screen from the Collect Action Screen



Coordinate Systems

The *Coordinate Systems* screen allows you to quickly access and create new coordinate systems based on the predefined systems with just a tap on this icon.

It is important to note that this screen does not set the current coordinate system for the *Project*. To change a *Project's* coordinate system choose *Project>Edit Current Project>Project Coordinate System* in the *Stake and Collect Prepare* screens. Each page in the *Project* can then also have separate coordinate systems, set from the *Page* and *Coordinate System* boxes in these screens.




Coordinate System Screen

Adding a State Plane Coordinate System


To add a new coordinate system that is currently not listed in the *Coordinate System* screen when the *All Project* button

is selected at the top of the screen, tap the  (Add) button to open the *Coordinate System Catalog*.



Coordinate System Catalog Screen

When selecting a Regional system for your project from the vast catalog, filter the choices to just those relative to your geographic location by checking the *Near Me* box. Select your Region, Country and type of coordinate system:




Creating an Adjusted Grid-To-Ground Coordinate System


It is important to remember that GNSS distances measured in State Plane Coordinate Systems may not match measured ground distances exactly and typically need to be scaled to ground.

With your state plane coordinate system selected in the *Coordinate System* screen click the *Additional Actions*


button  and tap *Duplicate* to create a copy of this coordinate system. The duplicated system will be created with the date appended to the end of its name:




Select the appropriate *Height System*, *Geoid*, *Input Epoch* and *Transformation*. The typical coordinate system configurations for a US State Plane Coordinate System is shown:



For latitudes south of 42N, "Geoid12B CONUS South 42N" should be chosen and for latitudes north of 40N, "Geoid12B CONUS North 40N" should be chosen.






Now highlight the duplicated system and tap the  icon and choose **Adjust Grid-to-Ground & Rename**:




Adjust Grid-to-Ground & Rename Screen


Tap the **Default** button  to change the coordinate system name to the default name:



Tap the position icon  beside East Origin to set origin point in the grid system for the transformation. Here the base station coordinate is chosen from the points List:




By default the ground origin point will be populated with the same coordinate and the **Scale Difference** is populated with the grid-to-ground scale factor calculated from that point. The scale factor rounded to the nearest part-per-million (ppm) is automatically appended to the coordinate system name:



You may also wish to round the scale difference to the nearest ppm by tapping its button and entering that value. In this screen options exist to enter a new factor as a Ratio

or Ppm:



The **Factors** button will allow you to use the CoGo Scale Factor function to calculate a new scale factor if desired.

These settings will create an adjusted state plane coordinate system scaled around the base station and the base station coordinate will not change. This is useful for projects that have ground distances as would be measured with a total station and state plane coordinate system bearings since the rotation is set to 0. The coordinates will be very close to the real state plane system so that orthographic imagery and state plane referenced contours or elevation models can be loaded into your CAD drawings. You should be cautious when giving these coordinates to others as they may confuse them for real state plane coordinates. To solve this problem you may wish to subtract 100,000 from the *North* and *East Ground* coordinate values to create a (100,000 100,000) offset from the real state plane system. This can be done by tapping the *North Ground* and *East Ground* boxes.

Tap the  button to add the current project's name to

the beginning of the coordinate system name:

Adjust Grid-to-Ground & Rename			
Name Project1 - NAD83(2011) / Ohio South NAVD 88 GRD: 50ppm			
North Origin	723889.5487 ft	East Origin	1784473.7876 ft
North Ground	723889.5487 ft	East Ground	1784473.7876 ft
Rotation	0°0'0.0"	Scale Difference	50.0 ppm
North Inclination	0.0 °	East Inclination	0.0 °
Vertical Offset	0.0 ft		

Press *OK* and then *Apply* to create this coordinate system:

Current Project	All Projects	Default
<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>

Grid System
Name Project1 - NAD83(2011) / Ohio South NAVD 88 GRD: 50ppm
Default name NAD83(2011) / Ohio South NAVD 88
Epoch 2010.0000
Geodetic Datum
Semi-major axis 6378137.000m
Inverse flattening 1 / 298.257222101
Prime meridian 00°00'00"
HTDP WGS84(ITRF2008) to NAD83(2011) / NAVD 88 / SPCS83

You can now use this coordinate system as the *Project Coordinate System* or just for some *Pages* if you choose.

Files and Data Exchange

Data transfers between the TRIUMPH-LS and your PC are facilitated through using either a USB cabled connection, a USB flash drive, a cloud drive or a network drive. Using a cloud drive or USB flash drive are the simplest and recommended methods to transfer data between your PC and J-Field.

Data Base Structure and Customize Screen

Each J-Field *Project* has a “data.db” file stored in its project folder found in “Internal Memory\ VS Data\Maps”. All the points and lines for a project are stored in this file. By default, the Internal Memory is hidden. To allow it to be visible in J-Field you can enable this option from *System>Customize*.

The *Long Click Time* setting in the *Customize* screen controls how long a button must be held down to register as a *Long Click*. Some button in J-Field perform two actions with the second action being initiated with a *Long Click*. Buttons with these second actions typically display a small down arrow in their bottom left corner.

Check the *Double Vial Detector* option if you are using the Javad rover rod with a double leveling vial. This allows the downward facing camera to detect both vials.

Customize		
Long Click Time		
Short <input checked="" type="radio"/>	Medium <input type="radio"/>	Long <input type="radio"/>
Double Vial Detector <input checked="" type="checkbox"/>		
Allow Browsing Files in Internal Memory <input checked="" type="checkbox"/>		
Cancel		Apply

Customize Screen

Working with WMDC

Using the provided micro USB Cable will allow you to browse the contents of the TRIUMPH-LS using Windows Mobile Device Center (WMDC); take care not to delete system files!


The first time that you connect the two devices, Windows will install Windows Mobile Device Center, a pretty straightforward process largely tailored to other types of mobile devices.



Click on 'Connect without setting up your device'



Click on 'File Management', and then 'Browse the contents of your device'



This is how the TRIUMPH-LS is seen by Windows

Windows operating system, J-Field, support files etc. are in the root directory.


When present, the attached USB dongle device will show here too

Survey projects are automatically assigned to their own folders at the time of the Project's creation and are similarly named as the project. All projects are in sub-folders beneath the parent folder 'Maps'

Good practice is to use the provided microSD card for survey-related data storage including Media, Photos, Screenshots and Spectrum data.


Mounting a Cloud Drive

J-Field supports [Google Drive](#) and [Dropbox](#) cloud drives.




Files>Browse Files screen showing mounted Google Drive, Dropbox and a shared network folder.


To mount a cloud drive navigate to <https://app.javad.com/jca/#/inventory/devices> and login from your PC's browser. If you have not setup a Javad.com login, you will need to do so.




After signing in you will be prompted to Grant access.



Click Generate Key and a new alphanumeric key will appear. In J-Field open System>Dropbox/Google Drive and tap Handshake Key to enter this key. Then click Establish Connection. Note that J-Field needs to have an Internet connection established during this process.




Once this is completed, return to your web browser and select Cloud accounts in the left pane. Then click Connect Google Drive or Connect Dropbox. You will be prompted for your credentials for these accounts.



After these steps are completed open Files>Browse Files and click the context menu icon  and choose Mount Cloud Drive. You should see your Google and Dropbox accounts listed if you completed the previous steps correctly. Choose the desired account and press OK.


Mounting a Shared Network Folder

Mounting a shared network folder allows files to be transferred to and from J-Field while it is connected to a local network. First a folder from a PC connected to the same local network as the TRIUMPH-LS needs to be created.



Here the folder TriumphLS was created on the Desktop. Right clicked on it, selected Properties and then enabled Sharing in the Sharing tab.


Then in the Browse Files screen, choose Mount Network Share from the File Operations menu when you are in the System Root directory.



Then enter the network path as shown above along with your Windows account name and password.




Press OK and you should now see this folder shared in the Root Directory where it can be used to import and export files.



Note that if an error message is received while trying to read the network shared folder, it may be necessary to reboot the TRIUMPH-LS to resolve this. This is a known issue with the Windows operating system in the TRIUMPH-LS.


Importing Points From a Text File

To import points from a text file open the *Data Exchange* screen from the *Home Screen 2* or from *Files>Data Exchange*.




Data Exchange Screen
www.javad.com

Navigate to the location where your file is located using the to go up a directory and *Open* to open a folder. Then select and highlight the text file to open and choose *Open*. (Notice the down arrow in the corner of the *Navigate Up* button. Holding this button down will initiate a *Long Click* and navigate to the system Root directory.)




Open File Screen - Filtered to show only text files

If your text file is configured with the standard format of "PointName, N, E, H, Description" you should configure the import settings as shown below if they are not presently configured this way. The preview should display if the format is being interpreted correctly.



If the preview is correct, press *Next*.



A summary screen will be displayed. The points will be imported into the selected *Page* and be imported to the coordinate system of that *Page*. Tap *Import* to finish importing the points.


Exporting Points To a Text File

To export points to a text file open the Data Exchange screen and choose the *Export* option. Choose the format of the file type you wish to export with the box in the lower right corner, in this case *Text/CSV*. Navigate to folder you wish to save the file. Click *Save File in This Folder* or the *New* button to proceed. If you desire to change the default filename of the file to be created, you may do so by clicking on the filename box displayed to the right of *Save File in This Folder*.




Save File Screen - Set to save a txt file in the USB drive

The *Export Formatting* screen will be displayed. It should have the default configuration to export a "PointName, N, E, H, Description" file with the description field being a merged field J-Field's *Code*, *Attributes* and *Description* fields. These fields are merged together with the use of *Sep. 2* (Separator 2) set to be a space. By default, fields are separated with *Sep. 1*, typically set to be a comma. Highlighting a field from the box on the left side of the screen and tapping *Sep. 2* will add a plus sign after the field name to indicate that it will be separated with *Sep. 2*.



Export Formatting Screen with Default Formatting Shown

The plus and minus buttons are used to add and remove fields while the up and down arrows will change the order of fields. *Presets* allows configurations to be saved and recalled. Options are displayed to set the number of *Decimals* exported and whether to export a *Header Line*. *More Settings* opens the *Export CSV Settings* screen where options exist to specify how to format cut and fill values and *Surveyed Design Points*.



Export CSV Settings Screen


www.javad.com

Use *Export Range* to choose which points to export.



What to Export Screen


After the settings and points to export have been selected, tap *Next* to preview the formatting and points before pressing *Export* to create the file.



Export File Preview Screen


Exporting Photos, Screenshots, GNSS Data and Project Archives

To export media files that include photos, screenshots, audio files and raw GNSS data files choose the **Project Archive File (ZIP)** format option in the **Save File** screen. A full **Project Archive** can also be exported with this option. A Project Archive contains all the files necessary to restore the project if it becomes corrupt or deleted. It can also be used to copy the project to a different TRIUMPH-LS.



Save File Screen - Set to save a Project Archive file in the USB drive


After tapping **Save File in This Folder** or the **New** button you will be presented with options to specify what type of files to export in the **Export Project Archive** screen. Use the **Full** option to create a backup that can be restored. The **Only Media** option will export only the filetypes chosen. Press **Create** to export the files which will all be contained in a zip file.



Export Project Archive Screen - Set to export only photos (screenshots included) and raw GNSS files


Exporting A Project Report

A report of the Project can be exported in HTML or PDF format by choosing **HTML** or **PDF** format in the **Save File** screen. The report will contain the selected points with all the details and statistics about that point. The **Text** & **Images** will be included if this option is checked. A number of options exist to format the PDF or HTML report:



ShapeTags & Codes


Create and manage your own library of **Codes**; alphanumeric textual assignments to points. **Codes** can quickly be recalled from the **Favorite Codes** screen, eliminating the need to type in a point description for each surveyed point. In addition, each **Code** can have up to five **Code Attributes** fields. An example of a **Code** is "IPF" (Iron Pin Found). It can then be setup with **Code Attribute** fields of "Size", "Cap" and "Status" which allow these attributes to be entered and stored with each point. Choose **Tags & Codes**>**Manage Codes** to access the library of **Codes**.



Manage Codes Screen

Tap **Create** or **Edit** to make a new **Code** or edit an existing one. A **Symbol**, **ID**, **Category** and **Code Description** can be assigned each **Code**. If a **Symbol** is associated with a **Code**, points with that code will have the **Symbol** displayed on the map. The **ID** field is a numerical field that is not used in J-Field but is an export option for text files and may be


useful with other software packages. The **Category** can be used as a filter in the **Manage Codes** screen.



Edit Code Screen

ShapeTags can be assigned to points during data collection to enable the automated drawing of lines between points with like **ShapeTags**. For example, you may want to create a **ShapeTag** of "Fence". When collecting a point along a fence, select the "Fence" **ShapeTag** to be assigned with that point. This will cause a line to be drawn on the map between that point and the previous point that also has the "Fence" **ShapeTag**.

ShapeTags are associated with a chosen **Code** when a new **ShapeTag** is created. When a **ShapeTag** is then selected to be assigned to a point, by default, the **Code** field for that point will be populated with the associated **Code**.



Setup


J-Field's settings are divided into 3 profile groups: the *General Group*, *Action Group* and *Favorite ShapeTags and Codes*. These groups exist so that different settings groups can quickly and easily be saved and recalled.

The **General Group** profile stores the settings for RTK corrections, i.e. the configurations for UHF radios or connection parameters to a RTN. The **Advanced Settings** are also stored in the *General Group* and are found as an option in the first setup screen of the *General Group*, they include the settings for the displayed units. Tap *Edit*>*Advanced* to access them. The configuration of the *Stake* and *Collect Action* screens' *User Defined* (whitebox) *Buttons* are stored in the *General Group* profile as well.

As an example, to configure a new RTN setup you would tap **Create** to create a new *General Group* profile and then follow the screen prompts to enter the communication parameters and settings. **Copy As** creates a copy of the existing profile but prompts you to enter a new name for the new profile.



The *(Set Up)* will quickly open the *Setup* screen; pressing it twice opens the *Advanced Settings* Screen.




Setup Screen



Advanced Settings Screen

Tapping the **Recall / Manage** button will open a list of profiles shown on the left side of the *Profiles* screen. Details of that profile are displayed in the information panel (the blue box on the right side of the screen). Across the top from left to right are buttons to **Rename**, **Delete**, **Search**, **Sort Alphabetically**, **Sort by Date**.




General Group Profiles Screen

The **Action Group** profile contains the collection settings. These include the RTK Verification and Validation settings and how many epochs to collect. These settings are discussed in the *Collect* section of this manual.




Action Setup Screen

The **Favorite ShapeTags & Codes** profile stores different list of favorite *ShapesTags* and *Codes*.



Setup Favorite ShapeTags & Codes Screen




Base/Rover Setup

Base/Rover Setup


Base/Rover Setup is used to configure and start the transmission of RTK corrections via UHF or FH915 SS (frequency hopping spread spectrum) radios from your Javad Base receiver and radio to your Rover. It reads the communication parameters from a UHF or SS *General Group* rover profile and creates a matching base station profile internally. It then sends that base station profile to the base through the Bluetooth connection.

Before *Base/Rover Setup* can be used a UHF or FH915 SS *General Group* rover profile is needed. If one does not exist yet, open the *Setup* screen and tap *Create* for a new *General Group* profile:



Setup Screen - Creating a new *General Group* profile

Enter a profile name ("UHF" or "FH915 SS" are suggested) in the next screen and tap *OK*. The next screen will prompt you to select the Operating Mode, choose RTK Rover:




You could tap *Next* and continue to configure all the communion parameters but this is not necessary as they can also be configured with *Base/Rover Setup*. Press *Back* and then *Esc* to return to the Home screen.

Once a UHF or FH915 SS *General Group* profile has been created and recalled, tap the *Base/Rover Setup* button from the second page of the *Home* screen.


If for some reason the selected profile is not in UHF or FH915 SS mode a message will be displayed indicating so.

Should that be the case, tap *Recall* to select a UHF or FH915 SS radio profile or tap the displayed message to change the current *General Group* profile into a UHF or FH915 SS profile.


To connect the Base and the Rover via Bluetooth, tap on *Connect*. The external radio, if using one, should be powered on prior to pressing *Connect*. Always have an antenna connected to the radio before powering it on to avoid potential damage to the radio.




Immediately a scan of available Bluetooth devices will begin and a few seconds later will be completed. Choose the device intended to be used as the Base receiver and tap **Connect**.



Once the Bluetooth connection has been initiated, it will take a few seconds before it has completed. During that interim few seconds, your screen may appear like what is shown on the right.



Once the existing Base and radio parameters have been retrieved the screen should look similar to this. The Rover profile radio parameters are displayed on the left panel while the current Base coordinate is displayed on the right. **Radio parameters displayed in red indicate that there is a different value between the Base and Rover profile. Use From Base to update the Rover profile to the parameters from the Base or use To Base to send the Rover radio parameters to the Base before starting the Base.**



Tapping the left panel opens the screen to configure the radio parameters. “RTCM 3.0 Min” **Format** should be used to minimize the correction data that must be sent through the radio. To start the base with **5 Hz BEAST MODE** corrections the **Broadcast Period** must be changed to **0.2 seconds**.


The time required to acquire a fix is inversely proportional to the rate of the corrections. By reducing the time for the RTK engines to fix, RTK *Verification* and *Validation* can be completed much quicker and surveyors can collect points in locations that previously proved to be very difficult and time consuming.

It is important to note that increasing the Broadcast Period, increases the battery consumption of the radio as well as the heat generation inside it. If you are using HPT401BT, HPT901BT or TRIUMPH-1 Internal Radio you will need to connect an external battery if you intend to operate the Base at 5 Hz for more than a few hours. With HPT435BT you may need to use the modem fan when broadcasting with an output power greater than 4 watts, depending upon the ambient temperature.


The **Base ID** field limits the Rover from receiving corrections if the Base and Rover profiles do not have the same **Base ID**. It can be left at its default value of 0.

Transmit L2C is always enabled. If for some reason it is not checked, it will become enabled automatically when the Base is started with **Base/Rover Setup**.

To configure the UHF or FH915 parameters tap the **UHF** or **FH915 Configuration** button.



UHF Base Configuration Screen



FH915 SS Base Configuration Screen

Tapping the **UHF** or **FH915 Configuration** button will trigger an immediate search for the radio via Bluetooth between the Base and the radio. If a Bluetooth enabled radio is not found to be currently paired to the Base, you will be prompted to pair the radio. This can be done via the Bluetooth option.



For UHF radios the parameters shown to the right need to be configured. The **Frequency** should be one of your FCC licensed (US users) frequencies. A channel with little interference should be chosen. From the **Frequency** selection screen you can **Scan** the displayed channels to check the interference levels.



UHF Configuration Screen

A **Modulation** (the method the data is encoded in the radio signal) must be selected that has a sufficient link rate to transmit increased data rates with 5 Hz corrections. If **Channel Bandwidth** is limited to 12.5 kHz by a FCC license, **D16QAM** modulation must be used. With 2 Hz corrections (0.5 second broadcast period) D8PSK modulation can also be used. Modulations with greater link rates have decreased receiver sensitivity to demodulate the signal and the downside to choosing modulations with higher link rates is that they are more subject to interference and data loss when the signal is weak. Field test have found that D16QAM modulation decreases the working range of the radio approximately 20% as compared to DQPSK modulation.

Increasing the **Output Power** increases radio range but also increases radio power consumption. With an antenna height 4 m (13.1 ft) and D16QAM modulation, 5 Hz RTK can

be stable up to 4 km (2.5 miles) away when terrain obstacles do not block the signal. A hill or ridge between the Base and Rover will greatly limit the range. The FCC (US) allows up to 35 watts ERP (Effective Radiated Power) to be transmitted. If you have a HPT435BT radio set to output 35 watts and are using an antenna that isn't a unity gain antenna, such as the 5 dBd gain whip antenna, you aren't in conformance with the FCC regulations and terms of your license. With the 5 dBd gain whip antenna, an **Output Power** of 10 watts or less must be used to stay under 35 watts ERP.

Your FCC assigned call sign should be entered in the **Call Sign** box.

The **Unpair** button is used to unpair the Bluetooth connection between the base and Rover. This would only be necessary if you wish to pair a different radio to your Base.

Update FW checks and installs the latest radio firmware. The versions released October of 2015 or later are needed for 5 Hz corrections to work correctly.

FH915 SS Radio Settings


With a **FH915 SS** radio **Packet Repeating** must be disabled when using correction rates greater than 1 Hz.

In the US it may be best to operate on **Channel 7** to avoid interference.

Field test confirm 4 km (2.5 miles) as the range at which stable 5 Hz RTK can be achieved with a **FH915 SS** radio with a 4 m (13.1 ft) antenna height. With 2 m you may achieve up to 2 km (1.2 miles), but it is dependent upon the environment.

UHF Modem Link Rates (bps)

Channel Spacing	Modulation			
	DBPSK	DQPSK	D8PSK	D16QAM
6.25 kHz	2,400	4,800	7,200	9,600
12.5 kHz	4,800	9,600	14,400	19,200
20 kHz	7,200	15,000	22,500	30,000
25 kHz	9,600	19,200	28,800	38,400



FH915 SS Configuration Screen

Return to main *Base/Rover Setup* screen by tapping *OK* twice. Press *To Base* to send modified parameters to the Base. After doing this all the parameter values should be yellow.

The Base broadcast coordinate should now be set. Tap on the coordinate pane on the right side of the screen.


If the base is being started on a known point select that point *From List* or *Enter* the coordinates manually; otherwise use an autonomous position by tapping *From Auto*.

The *2D Delta* indicates the horizontal distance between the current autonomous position the base is reporting and the proposed broadcast coordinate.

Enter the *Antenna Height* and *Offset*. In this case the Base is on a 2 m pole with the thread adapter that adds an additional 0.025 m. Tap *OK* once done.

The base station raw GNSS data is always recorded and then transferred to J-Field when *Stop Base* is pressed at the end of a survey session so that it can be sent to Javad's *Data Processing Online Service*, also known as *DPOS*. With the *DPOS* tool found in the *CoGo* menu the raw data file can be submitted to *DPOS* and all the survey points from that base station session can be adjusted to their real coordinates so they are no longer based off an autonomous position. The recording interval can be specified along with some *DPOS* options with the *Rec* box.

Once the coordinates for the Base have been selected/entered along with *Antenna Height* and radio parameters tap *Start Base*.




In this screen you can enter / change the name of the point being used as the base; to do so, tap *Stored Point Name* and enter the desired name. It is recommended the Project Name being included in the point name so that the file can easily be identified in the *DPOS* tool.

Confirm sending the coordinates to the Base with a tap on *Yes, Store Point and Send to Base*.

The parameters will be sent to the Base and radio and the Base should begin to broadcast, typically after about 80 seconds.

The  (transmit) icon will indicate when the Base is transmitting and OK will be displayed to the right of it.

Similarly, the  (receive) will indicate when the Rover is receiving data. If the icon bars are red (as shown with one red bar), this indicates that the radio transmission is over powering the receiving radio and that the Rover is too close for set *Output Power*. If the broadcast is too overpowering, corrections will be lost and the link quality will drop.




Once the Base is broadcasting you can check that the Rover is correctly receiving corrections at the set transmission rate. Open the *Collect* or *Stake Action* screen. The position solution button should display the correct incoming correction rate and the communication button should display a 100% link quality.



To check that you have started the Base correctly with the correct coordinate, you may wish to stake a point you have previously located if you have one available.

After the Base has been started you can press *Done* to disconnect the bluetooth or alternatively the connection will be disconnected when the distance between the Base and Rover exceeds the range of the Bluetooth communication.



After finishing surveying return to the Base again and open *Base/Rover Setup* to *Connect* again and stop the base with *Stop Base*. This will display a prompt to stop the data transmissions and download the Base GNSS data into J-Field. Choose *Stop & Download*. After the download completes the Base can be powered off, the radio can be powered off while the data is downloading without causing any problems.CFG if this is the case.

Troubleshooting Starting the Base

If for some reason problems are encountered when trying to start the Base, clearing the Base NVRAM is usually the first recommendation.

How to clear the NVRAM

1. Turn the receiver OFF with the ON/OFF button.
2. Press and hold the Record button.
3. Turn the receiver ON by pressing the ON/OFF button.
4. Wait until all the LEDs are flashing yellow (except the battery LED).
5. Release the Record button.

If the radio is transmitting, its TX LED should be flashing at the broadcast rate. If the radio is broadcasting but corrections are not being received in J-Field, check the *UHF Status* screen for an "err" listed in the *UHF State*. If an error state is displayed, press *Restore CFG* to restore the factory UHF configuration.

UHF			
Region	ALL	Data RX	RTCM 3.0
Output Power	--	Sent	--
Frequency	451.80000 MHz	Station ID	N/A
Protocol	JAVAD	Distance	N/A, no base coord.
Modulation	D16QAM	LQ, Delay	,
Ch. Bandwidth	12.5 KHz	Data link latency	7.0 sec
FEC, Scrambling	On, 255	Received, Lost	--, 0
Link Rate	19200 bps		
Call Sign	--		
Antenna	Internal		
RSSI	No signal (-147 dBm)		
BER	--		
UHF State	err, freq		

Esc Configuration > Restore CFG >

UHF Status Screen - UHF State "err, freq", Use Restore CFG to repair



Collect

Pressing the *Collect* button opens the *Collect Prepare* screen; pressing *Collect* hardware button twice will open the *Collect Action* screen.



In the *Collect Prepare* screen, the *Project*, *Page*, *Coordinate System*, *ShapeTag*, *Code*, *Code Attributes*, *Point Name*, *Point Description*, *Antenna Height* and collection settings can be setup before beginning data collection for a point.


When collecting points, it is recommended to use the *Code* and *Code Attributes* to store information about the point being collected. The *Description* field can then be reserved for entering additional information about the point. When exporting point coordinates in Text/CSV format, these three fields can be merged into one field so that surveying software can import data with the traditional "Name,N,E,H,Description" format but with the description being the combination of J-Field's *Code*, *Code Attributes* and *Point Descriptions* fields.

The *Review* buttons opens the *Review* screen which is a map of the project. Here linework can be drawn on the map with the CAD functions and point data can be edited.

The *View* button opens a screen to configure what point attributes are displayed on the map and allows some graphical parameters to be customized.

To the right of the *View* button is the *Action Setup* button

which opens a screen to configure the collection settings for points. The RTK Verification and Validation settings are configured from *Action Setup* screen.



Collect Prepare Screen



Pressing the *Action* hardware button or *Next* from the *Collect Prepare* screen opens the *Collect Action* screen.

Screen Anatomy - Collect Prepare Screen

The *Project* button displays the name of the current *Project*. Tap it to open an existing *Project*, to create a new *Project*, or to edit the current *Project*'s name or coordinate system.

The *Page* button displays the name of the current *Page*. Tap it to open the *Pages* screen and set the current *Page*, turn on or off *Pages* or edit a *Page* Name or coordinate system.

The *Coordinate System* button displays the name of the coordinate system for the current *Page*. Tap it to change this coordinate system.

ShapeTags can be assigned to points during data collection to enable the automated drawing of lines between points with like *ShapeTags*. "DefTag" is the default *ShapeTag* and does not create lines between points.

The *Code* button displays the name of the *Code* that will be assigned to the next surveyed point. Tap it to choose a new *Code* from your list of *Favorite Codes*.

Up to five variable *Code Attributes* fields can be used to store additional information about a point with this box.

The *Point Name* button displays the name that will be assigned to the next surveyed point. After a point is surveyed it will increment to the next available name.

Edit the height of the ARP (Antenna Reference Point).

The *Review* buttons opens the *Review* screen which is a map of the project. Here linework can be drawn on the map with the CAD functions and point data can be edited.

Takes you to the *Action* screen

Use the *Point Description* field to store additional information about the point.


The *View* button opens a screen to configure what point attributes are displayed on the map and allows some graphical parameters to be customized.

Displays the current *Action Group* profile name group and opens the *Action Setup* screen. The rover icon displays whether tilt corrections are enabled or not (disabled above). The clock icon indicates the *How to Stop?* setting has been set to a fixed number of epochs.

Displays the estimated remaining battery life and is a shortcut to the *Battery Status* screen

Action Profile Setup

The **Action Setup** screen can be opened by tapping the bottom middle button on the *Collect* and *Stake Prepare* screens. It contains all the settings related to the collection of points.




Action Setup Screen - Recommended Settings for Multipath Environments

There several different options to specify when data collection for points starts and ends, the most commonly used options being with the *Start Button* and after a specified number of epochs have been collected. Using a **Start Delay** may be useful if you need to collect a point where you cannot reach the TRIUMPH-LS. You can press Start and then set the TRIUMPH-LS up over the desired point. The starting of data collection will be delayed by the selected *Delay* period.



How to Start Screen




How to Stop Screen - Recommended Settings for Surveying Monuments in Multipath Environments with 5 Hz BEAST MODE Corrections

What To Record presents options to automatically capture raw GNSS data, camera images, voice recordings and screenshots.

Use **Recall** to quickly recall a saved Action Group profile. This is useful for changing the collection settings for different

environments and types of points that need to be collected.

If **Activate Post-Processing** is enabled, raw GNSS data will always to be logged in the background when points are collected. If an RTK solution has not been accepted or rejected after the set period of time, options will be presented during point collection to save the GNSS data with the point for post-processing.



Activated Post-Processing Prompt after a fixed solution was not able to be collected.



RTK Verification and Validation

It is very important that you read and understand the information about RTK Verification and Validation contained in this manual.

Verify Settings Screen - Recommended Settings for Multipath Environments

When located in difficult environments and under tree canopy, all GNSS receivers are prone to give bad fixed solutions that may appear to be acceptable if they are not verified. Existing methods to verify GNSS solutions include “dumping” the receiver, turning it upside down to cause the RTK engines to reset, and re-observing the point at a later time.

J-Field automates these processes with its built-in software features of *Verify* and *Validate*. *Verify* automatically resets the RTK engines after every fixed epoch is collected in *Phase-1* of its process. Epochs are placed into *Groups* or buckets during *Phase-1*. Once a *Group* has the required *Confidence Level* *Phase-1* is complete.

The *Confidence Guard (CG)* determines the size of the *Group* or bucket. Each *Group* contains all the epochs located within a specified radius (the *CG* value) from its center and new *Groups* are created as necessary so that all epochs fall into at least one *Group*. Each *Group* has its own *Epoch Counter*, *Confidence Level* and *Elapsed Time*. A point may fall into more than one group. The current best group is shown within [] and others within ().

The number of groups is limited by the Max Groups setting. If this number of groups is exceeded, *Phase-1* will reset and start over. During *Phase-1*, the current best group will be displayed between the square brackets [] while the other groups are displayed between parenthesis ().

During *Phase-2* the engines are not reset and solutions which are located inside the *CG* of the selected *Group* are added to that *Group* for the remaining number of epochs that user has requested (*Epoch Number, EN*) in the *How to Stop* screen. Solutions which are outside the *CG* of the selected *Group* will be ignored; the RTK engines are reset if the epoch falls outside a sphere with a radius twice that of the *CG*. If the number of rejected epochs reaches 30% of epochs collected so far, the whole process will restart.

Validation is the final step of the process. With this feature enabled the RTK engines will reset one final time at the end of the observation and collect 10 additional epochs. Allowing sufficient time between *Phase-1* and the final *Validation* step will guarantee a bad solution is not allowed to be accepted. From extensive testing in the worst of multipath environments, a bad solution has yet to be accepted when *Verify* and *Validate* are enabled with *Phase-2* collecting epochs for at least 120 seconds. To accomplish this, set stop *After (EN)* to 120 epochs with 1 Hz corrections, 240 epochs with 2 Hz corrections or 600 epochs with 5 Hz corrections.

Confidence Level and *Consistency Level* are counters; the *Confidence Level* of a group increments each time an epoch with a new RTK initiation (Fix) is collected. It increments by values of 1, 1.25, 1.5, 1.75, 2.0, or 2.5 for 1 to 6 fixed engines, respectively. The *Consistency Level* of a group increments with every epoch collected by values of 0, 0.1, 0.25, 0.5, 1.0, and 1.5 for 1 to 6 fixed engines. The set *Consistency Level* must be met before *Phase-2* is allowed to end.

If high accuracy is needed in areas of high multipath and areas with limited views of open sky (under full tree canopy and urban canyon environments), longer observations will improve accuracy. Repeated observation can also be performed later (1 hour or more is recommended) to improve accuracy. These repeated points can then be averaged together with the *Average* function found in *Cogo Tools* or with the *Cluster Averaging* function.

Recommended Collection Settings

Control, Boundary and Multipath Environments

- ◆ Start with Start Button
- ◆ Stop After: 120(1 Hz), 240(2 Hz) 600(5 Hz) epochs, may be reduced to 30 in open sky
- ◆ Verify with V6 Reset
- ◆ Confidence Level: 5 to 10 (10 will cause *Phase-1* to take long but results in less incorrect *Phase-1* positions)
- ◆ Consistency Counter: 10
- ◆ Min RTK Engines: At least 2
- ◆ Validate Result: with at least 2 engines
- ◆ Correct for Tilts: Off (Rover pole must be plumbed)

Precise Topographic

- ◆ Start with Start Button or Start When Tilted

- ◆ Stop After: 10 epochs
- ◆ Verify with V6 Reset
- ◆ Confidence Level: 5
- ◆ Consistency Counter: 10
- ◆ Min RTK Engines: At least 2
- ◆ Validate Result: with at least 2 engines
- ◆ Correct for Tilts: On*

Quick Topo for use with Open Sky Environments

- ◆ Start with Start Button or Start When Tilted
- ◆ Stop After: 2 epochs
- ◆ Verify without V6 Reset
- ◆ Consistency Counter: 0
- ◆ Min RTK Engines: At least 4
- ◆ Correct for Tilts: On*

In all cases

- ◆ Accept Fixed Only, RMS: All, PDOP: All
- ◆ Confidence Guard: 0.164 ft

If you wish to review point statistics or if you wish to edit the ShapeTag, Code, Description and/or Attributes fields after data collection, Auto Accept must be set to Off. If these fields do not need to be changed and you desire fast data collection with the Quick Topo settings, set Auto Accept to On.

*If Correct for Tilts is on, the Level Offsets must be calibrated frequently if accuracies greater than 0.10' are needed.

If the point you are attempting to locate is near the edge of a building, tree trunk or other obstruction, it often best to use one of the CoGo Offset functions. When the most accurate measurements are needed, the *CoGo Resection* function found in the *Intersections* group is recommended.

Screen Anatomy - Collect Action Screen

Instantaneous RMS estimate of the current position solution

The current RTK correction rate being received

“FIX” (Fixed), “FLT” (Float), “CDF” (WAAS Code Differential Float) or “STN” (Standalone) solution types are indicated. Tap this box to open the RTK V6+ screen..

Number of engines fixed/number of engines required by user
Returns to the previous screen

Shortcut to *Satellite Status* screen; SV total*

Maximizes map view to full screen

Shortcut to the *Review* screen

Cycle through *AutoZoom* and *1:1 Zoom* modes

Zoom out

Unassigned User Defined Button, tap to assign

Shortcut to the *Action Setup* screen; the pitch (forward/back), roll (left/right), and the azimuth or bearing the unit is facing are displayed. This box turns orange if the device is tilted more than 5° with *Correct for Tilts* off, or more than 30° degrees with *Correct for Tilts* enabled. When orange it prevents accepting of epochs in all modes except trajectory.

Shortcut to the applicable RTK corrections communications screen; Currently corrections are being received through WiFi with a 100% link quality and full signal strength (as displayed by the full bars of the signal strength icon)

Begin collecting a point; the current time is displayed on the 2nd line

Shortcut to *Selection* of the type of feature being located; *Point, Line Curve, Trajectory* or *Shift*; choose by *Survey* or by *Offset*

Antenna Height

D-SNR loss, displays the level (in dB) of the signal strength loss and interference in the L1 / L2 GPS and GLONASS bands. Values 0-3 are desirable, 3-6 are fair and above 6 are poor.

Center map on current location

Zoom in, the scale is displayed as the distance across the bottom of the screen (between the user defined boxes).

Current location in current Page

Tap once to perform the action associated with the *User Defined Button* (AKA *Whitebox*); long click (touch and hold) to remove or change the *User Defined Button* from

The map displaying point and lines contained in pages that are enabled. To expand the *User Defined Buttons* press the *Action* hardware button.

* Total number of SVs observed by RTK Rover may be different from number of SVs observed by RTK Base

Screen Anatomy - RTK V6

GNSS satellite count used in given engine

3D RMS for the current epoch in given engine

Number of seconds since the last reset for a given engine

Distance from the solution of the 1st engine

Number of fixed solutions since all engines were reset

Use this value to evaluate and compare the performance of each engine.

Charts plotting each fixed epoch for each engine

Manually reset engines to compel new fixed solutions when automatic verification is turned off (unchecked)

A user definable threshold showing allowable delay in seconds when *Extrapolation Mode* is used.


Reset GNSS Tracking

RTK V6+ support float engine: 1.919ft (97)					
GPS	GLONASS	GPS	GLONASS	GPS	GLONASS
7	5	7	5	7	5
Fixed	Fixed	Fixed	Float	Float	Float
0.071ft	0.071ft	0.071ft	3.89ft	3.89ft	5.36ft
97	97	97	37	37	22
0.000ft	0.000ft	0.000ft	1.739ft	1.739ft	2.536ft
85	85	85	1	1	0

Screen Anatomy - Collect Action Screen

Screenshot after Phase-1 of RTK Verification is Completed

Time: Duration is seconds between the first and last epoch collected



Current epoch count

Current best group in []

Current other groups in ()

Current confidence level

Target confidence level

* At the end of Verify sets values shown are the total RMS of all sets

Horizontal (left) and vertical (right) plots of the collected epochs. Each Group has its own color. These plots currently have 2 Groups.

Verify Statistics
of Phase-1 Restarts, # of Groups
of Epochs outside the Confidence Guard during Phase-2

Scales of the plots
Horizontal Vertical

Coordinates of current position


Example One: Phase-1 ONE

This Point was collected in a high multipath environment, several feet away from a 2 story building.

Screen Anatomy - Map Screen

Screenshot after Phase-2 and Validation Phase of RTK Verification is Completed

Confidence Level of the Point
Number of epochs used in final position
Time between first and last epoch in seconds
Consistency Level of the Point
HRMS and VRMS of the Point in units of 0.01 ft



Confidence Level of the Point

Number of epochs used in final position

Time between first and last epoch in seconds

Consistency Level of the Point

HRMS and VRMS of the Point in units of 0.01 ft

Verify Statistics
of Phase-1 Restarts, # of Groups
of Epochs outside the Confidence Guard during Phase-2

Vertical Drift in mm per minute (RMS of the Vertical Drift)

Final averaged position of all positions

Peak to peak distance
Horizontal Vertical
Current page's linear units

Example One: Phase-2

This Point was collected in a high multipath environment, several feet away from a 2 story building. The effect of multipath can be seen with the large vertical spread displayed in the vertical plot.

Screen Anatomy - Collect Action Screen with Expanded User Defined Buttons

The *User Defined Buttons* are expanded by pressing the Action hardware button. The most commonly used and recommend User Defined Button options are shown below:



Many of the selected options are inputs for the same parameters in the *Collect Prepare* screen. As with every screen, more details can be found by pressing the *Help* hardware button.



Stake


Similar to the *Collect Prepare* screen in appearance and function, the *Stake Prepare* screen allows you to configure the settings for staking points.



Stake Prepare Screen

Additionally, the *Prepare to Stake* screen allows you to define various *Modes* to stake which include a *Points Mode*, several *Alignment Points Mode* and *Alignment Stake-Here Mode*.

Sequence defines the order of the points to be stake. The *From Map* mode is suggested mode for new users. This allows you to pan the map cursor over a point displayed in the map and tap *Next* to select that point to be staked.



Stake Sequence Screen


The suggested *User Defined Button* options for new users are displayed in the follow two screenshots.



Stake Action Screen

When near the target point being staked tap *Start* to begin collecting data and to average the displayed offset values. When staking a point in a multipath environment, this is an essential step that must be used with *RTK Verification* to ensure the RTK initiation is correct. Choose *Accept* to store

the staked coordinate or *Reject* to discard them or to adjust the position and try again.



Stake Action Expanded Screen

The *CTT* (Course to Target) *Arrow User Defined Button* option in the top left box displays the direction to the point being staked while the distance to it is displayed in the *DTT* (Distance to Target) whitebox below it. Further down are the *Ahead/Back* and *Right/Left* boxes that display the distances to the point relative to the TRIUMPH-LS. The *Cut/Fill* option is in the lower right box.

On the right side, the *Target Name* option is used as another method to select the point being staked. When it is added as a whitebox you must choose whether to “Key-in target point name” or “Select target point from list”. Select the option you prefer. Below it are *Point Description*, *Accept As* and *Verify Statistics* whitebox options.

The *Accept As* whitebox is useful if you wish to store the staked coordinate of a design point as new point rather than having it stored in the design point’s record. After collecting the staked design point press *Accept As* rather than *Accept* if you desire to store it as a new point.



FIELD

900 Rock Avenue, San Jose, CA 95131 USA

Phone: +1(408)770-1770

Fax: +1(408)770-1799

www.javad.com

Copyright © JAVAD GNSS, Inc., 2016

All rights reserved. No unauthorized duplication.

